

WING

XW260K

1. GENERAL WARNING

1.1 PLEASE READ BEFORE USING THIS MANUAL

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.

1.2 SAFETY PRECAUTIONS

- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- Fit the probe where it is not accessible by the End User. The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "Dixell s.r.l." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

2. GENERAL DESCRIPTION

Model **XW260K** is microprocessor based controller suitable for applications on medium or low temperature refrigerating units. It must be connected by means of a two-wire cable ($\varnothing$ 1mm) at a distance of up to 30 meters to the keyboard **T620**. It is provided with four relay outputs to control compressor, defrost - which can be either electrical or hot gas - the evaporator fans and the lights.

It is also provided with three NTC probe inputs, one for temperature control, one to control the defrost end temperature of the evaporator and the third, optional, for the display. There are two digital inputs (free contact) for the door switch and configurable by parameter.

The standard TTL output allows the user to connect, by means of a TTL/RS485 external module, a **ModBUS-RTU** compatible monitoring system and to programme the parameter list with the **"Hot Key"**. An optional output for **RS485** direct is available.

3. CONTROLLING LOADS

3.1 THE COMPRESSOR

The regulation is performed according to the temperature measured by the thermostat probe with a positive differential from the set point: if the temperature increases and reaches set point plus differential the compressor is started and then turned off when the temperature reaches the set point value again.

In case of fault in the thermostat probe the start and stop of the compressor are timed through parameters **"CON"** and **"COF"**.

3.2 FAST FREEZING

When defrost is not in progress, it can be activated the keypad by holding the **è** key pressed for about 3 seconds. The compressor operates in continuous mode for the time set through the **"CCt"** parameter. The cycle can be terminated before the end of the set time using the same activation key, **è** for about 3 seconds.

3.3 DEFROST

Three defrost modes are available through the **"IdF"** parameter: defrost with electrical heater, hot gas or thermostatic defrost. The defrost interval is control by means of parameter **"EdF"**: (EdF=in) the defrost is made every **"IdF"** time, (EdF=Sd) the interval "IdF" is calculate through Smart Defrost algorithm (only when the compressor is ON and the evaporator temperature is bigger than "SdF" parameter). At the end of defrost the drip time is controlled through the **"FdT"** parameter.

3.4 CONTROL OF EVAPORATOR FANS

The fan control mode is selected by means of the **"FnC"** parameter:

- C-n** = running with the compressor, OFF during the defrost;
- C-y** = running with the compressor, ON during the defrost;
- O-n** = continuous mode, OFF during the defrost;
- O-y** = continuous mode, ON during the defrost;

An additional parameter "FSI" provides the setting of temperature, detected by the evaporator probe, above which the fans are always OFF. This can be used to make sure circulation of air only if his temperature is lower than set in "FSI".

4. KEYBOARD



set To display and modify target set point; in programming mode it selects a parameter or confirm an operation. By holding it pressed for 3s when max or min temperature is displayed it will be erased.

up To see the max. stored temperature; in programming mode it browses the parameter codes or increases the displayed value. By holding it pressed for 3s the fast freezing cycle is started.

down To see the min stored temperature; in programming mode it browses the parameter codes or decreases the displayed value.

defrost By holding it pressed for 3s the defrost is started.

light Switch ON and OFF the cold room light.

power Switch ON and OFF the instrument.

KEY COMBINATIONS

up + **down** To lock and unlock the keyboard.

set + **down** To enter the programming mode.

set + **up** To exit the programming mode.

4.1 USE OF LEDS

Each LED function is described in the following table.

LED	MODE	Function
	ON	The compressor is running
	FLASHING	- Programming Phase (flashing with LED) - Anti-short cycle delay enabled
	ON	The fan is running
	FLASHING	Programming Phase (flashing with LED)
	ON	The defrost is enabled
	FLASHING	Drip time in progress
	ON	The Fast Freezing cycle is enabled
	ON	- ALARM signal - In "Pr2" indicates that the parameter is also present in "Pr1"

Function of the LEDs placed on the left top side of buttons:

BUTTON	MODE	FUNCTION
SET	FLASHING	The Set point is displayed and it can be modified
SET	FAST FLASHING	The Energy Saving is enabled
DEFROST	ON	The Manual Defrost is activated
LIGHT	ON	The Light is ON
ON/OFF	ON	The instrument is OFF

4.2 HOW TO SEE THE MIN TEMPERATURE

- Press and release the **à** key.
- The "Lo" message will be displayed followed by the minimum temperature recorded.
- By pressing the **à** key or waiting for 5s the normal display will be restored.

4.3 HOW TO SEE THE MAX TEMPERATURE

- Press and release the **è** key.
- The "Hi" message will be displayed followed by the maximum temperature recorded.
- By pressing the **è** key or waiting for 5s the normal display will be restored.

4.4 HOW TO RESET THE MAX AND MIN TEMPERATURE RECORDED

- To reset the stored temperature, when max or min temperature is displayed :
- Press SET key until "YST" label starts blinking.

N.B. After the installation RESET the temperature stored .

4.5 HOW TO SEE AND MODIFY THE SET POINT

- Push and immediately release the **SET** key: the display will show the Set point value;
- The SET LED start blinking;
- To change the Set value push the **è** or **à** arrows within 10s.
- To memorise the new set point value push the **SET** key again or wait 10s.

4.6 TO START A MANUAL DEFROST

- Push the **DEF** key for more than 2 seconds and a manual defrost will start.

4.7 TO ENTER IN PARAMETERS LIST "PR1"

To enter the parameter list "Pr1" (user accessible parameters) operate as follows:

- Enter the Programming mode by pressing the Set and DOWN key for few seconds (and start blinking).
- The instrument will show the first parameter present in "Pr1"

4.8 TO ENTER IN PARAMETERS LIST "PR2"

To access parameters in "Pr2":

- Enter the "Pr1" level.
- Select "Pr2" parameter and press the **"SET"** key.
- The "PAS" flashing message is displayed, shortly followed by "0 - -" with a flashing zero.
- Use **è** or **à** to input the security code in the flashing digit; confirm the figure by pressing **"SET"**. The security code is "321".
- If the security code is correct the access to "Pr2" is enabled by pressing **"SET"** on the last digit.

Another possibility is the following: after switching ON the instrument the user can push Set and DOWN keys within 30 seconds.

NOTE: each parameter in "Pr2" can be removed or put into "Pr1" (user level) by pressing **"SET"** + **à**. When a parameter is present in "Pr1" LED () is on.

4.9 HOW TO CHANGE THE PARAMETER VALUE

- Enter the Programming mode.
 - Select the required parameter with **è** or **à**.
 - Press the **"SET"** key to display its value (and LED starts blinking).
 - Use **è** or **à** to change its value.
 - Press **"SET"** to store the new value and move to the following parameter.
- To exit: Press **SET** + **UP** or wait 15s without pressing a key.
- NOTE:** the new programming is stored even when the procedure is exited by waiting the time-out.

4.10 HOW TO LOCK THE KEYBOARD

- Keep the **è** and **à** keys pressed together for more than 3 s the **è** and **à** keys.
- The "POF" message will be displayed and the keyboard is locked. At this point it is only possible the viewing of the set point or the MAX o Min temperature stored and to switch ON and OFF the light, the auxiliary output and the instrument.

TO UNLOCK THE KEYBOARD

Keep the **è** and **à** keys pressed together for more than 3s.

4.11 ON/OFF FUNCTION

By pushing the **ON/OFF** key, the instrument shows "OFF" for 5 sec. and the ON/OFF LED is switched ON. During the OFF status, all the relays are switched OFF and the regulations are stopped; if a monitoring system is connected, it does not record the instrument data and alarms.

N.B. During the OFF status the Light and AUX buttons are active.

4.12 TO SEE THE PROBE VALUES

- Enter in "Pr2" level.
- Select **"Prd"** parameter with **è** or **à**.
- Press the **"SET"** key to display **"Pb1"** label alternate with Pb1 value.
- Use **è** and **à** keys to display the other probe values.
- Press **"SET"** to move to the following parameter.

5. PARAMETER LIST

REGULATION

Hy **Differential:** (0,1÷25,5°C; 1÷45°F): Intervention differential for set point, always positive. Compressor Cut IN is Set Point Plus Differential (Hy). Compressor Cut OUT is when the temperature reaches the set point.

LS **Minimum set point limit:** (-50,0°C÷SET; -58°F÷SET) Sets the minimum acceptable value for the set point.

US **Maximum set point limit:** (SET÷110°C; SET÷230°F) Set the maximum acceptable value for set point.

Ods **Outputs activation delay at start up:** (0÷255 min) This function is enabled at the initial start up of the instrument and inhibits any output activation for the period of time set in the parameter. (AUX and Light can work)

AC **Anti-short cycle delay:** (0÷30 min) interval between the compressor stop and the following restart.

CCt **Thermostat override:** (0min ÷23h 50min) allows to set the length of the continuous cycle. Can be used, for instance, when the room is filled with new products.

Con **Compressor ON time with faulty probe:** (0÷255 min) time during which the compressor is active in case of faulty thermostat probe. With CON=0 compressor is always OFF.

COF **Compressor OFF time with faulty probe:** (0÷255 min) time during which the compressor is off in case of faulty thermostat probe. With COF=0 compressor is always active.

DISPLAY

CF **Temperature measurement unit:** °C = Celsius; °F = Fahrenheit . When the measurement unit is changed the SET point and the values of the regulation parameters have to be modified

rES **Resolution (for °C):** (in = 1°C; de = 0,1°C) allows decimal point display.
de = 0,1°C
in = 1 °C

Red **Remote display** : select which probe is displayed by the remote display (**T620**)

P1 = Thermostat probe

P2 = Evaporator probe

P3 = auxiliary probe

1r2 = difference between P1 and P2 (P1-P2)

DEFROST

IdF **Defrost type:**

rE = electrical heater (Compressor OFF)

rT = thermostat defrost. During the defrost time "MdF", the heater switches On and OFF depending on the evaporator temperature and "dtE" value.

in = hot gas (Compressor and defrost relays ON)

EdF **Defrost mode:**

in = interval mode. The defrost starts when the time "IdF" is expired.

Sd = Smartfrost mode. The time IdF (interval between defrosts) is increased only when the compressor is running (even non consecutively) and only if the evaporator temperature is less than the value in **"SdF"** (set point for SMARTFROST).

SdF **Set point for SMARTFROST:** (-30÷30 °C/ -22÷86 °F) evaporator temperature which allows the IdF counting (interval between defrosts) in SMARTFROST mode.

dtE **Defrost termination temperature:** (-50,0÷110,0°C; -58÷230°F) (Enabled only when the evaporator probe is present) sets the temperature measured by the evaporator probe which causes the end of defrost.

IdF **Interval between defrosts:** (1÷120h) Determines the time interval between the beginning of two defrost cycles.

MdF **(Maximum) duration of defrost:** (0÷255 min) When **P2P** = **n**, no evaporator probe, it sets the defrost duration, when **P2P** = **y**, defrost end based on temperature, it sets the maximum length for defrost.

dFd **Display during defrost:**

rt = real temperature;

it = temperature reading at the defrost start;

Set = set point;

dEF = "dEF" label;

dEG = "dEG" label;

dAd **Defrost display time out:** (0÷255 min) Sets the maximum time between the end of defrost and the restarting of the real room temperature display.

Fdt **Drain down time:** (0÷60 min.) time interval between reaching defrost termination temperature and the restoring of the control's normal operation. This time allows the evaporator to eliminate water drops that might have formed due to defrost.

dPO **First defrost after start-up:**

y = Immediately;

n = after the IdF time

dAF **Defrost delay after fast freezing:** (0min÷23h 50min) after a Fast Freezing cycle, the first defrost will be delayed for this time.

FANS

FnC **Fan operating mode:**

C-n = running with the compressor, OFF during the defrost;

C-y = running with the compressor, ON during the defrost;

O-n = continuous mode, OFF during the defrost;

O-y = continuous mode, ON during the defrost;

Fnd **Fan delay after defrost:** (0÷255 min) The time interval between the defrost end and evaporator fans start.

FSt **Fan stop temperature:** (-50÷110°C; -58÷230°F) setting of temperature, detected by evaporator probe, above which the fan is always OFF.

ALARMS

ALC **Temperature alarm configuration**

rE = High and Low alarms related to Set Point

Ab = High and low alarms related to the absolute temperature.

ALU **High temperature alarm setting:**

ALC= rE, 0 ÷ 50°C or 90°F

ALC= Ab, ALL ÷ 110°C or 230°F

when this temperature is reached and after the ALd delay time the HA alarm is enabled.

ALL **Low temperature alarm setting:**

ALC = rE , 0 ÷ 50 °C or 90°F

when this temperature is reached and after the ALd delay time, the LA alarm is enabled..

AFH **Temperature alarm and fan differential:** (0,1÷25,5°C; 1÷45°F) Intervention differential for temperature alarm set point and fan regulation set point, always positive.

ALd **Temperature alarm delay:** (0÷255 min) time interval between the detection of an alarm condition and the corresponding alarm signalling.

dAO **Delay of temperature alarm at start-up:** (0min÷23h 50min) time interval between the detection of the temperature alarm condition after the instrument power on and the alarm signalling.

EdA **Alarm delay at the end of defrost:** (0÷255 min) Time interval between the detection of the temperature alarm condition at the end of defrost and the alarm signalling.

dot **Delay of temperature alarm after closing the door** : (0÷255 min) Time delay to signal the temperature alarm condition after closing the door.

doA **Open door alarm delay:**(0÷255 min) delay between the detection of the open door condition and its alarm signalling: the flashing message **"dA"** is displayed.

nPS **Pressure switch number:** (0 ÷15) Number of activation of the pressure switch, during the **"did"** interval, before signalling the alarm event (I2F= PAL).

PROBE INPUTS

Ot **Thermostat probe calibration:** (-12,0÷12,0°C/ -21÷21°F) allows to adjust possible offset of the thermostat probe.

OE **Evaporator probe calibration:** (-12,0÷12,0°C/ -21÷21°F) allows to adjust possible offsets of the evaporator probe.

O3 **Auxiliary probe calibration:** (-12,0÷12,0°C/ -21÷21°F) allows to adjust possible offsets of the evaporator probe.

P2P **Evaporator probe presence:**

n= not present: the defrost stops only by time; **y**= present: the defrost stops by temperature and time.

P3P **Auxiliary probe presence:** **n**= not present; **y**= present.

HES **Temperature increase during the Energy Saving cycle** : (-30,0°C ÷ 30,0°C / -22÷86°F) sets the increasing value of the set point during the Energy Saving cycle.

DIGITAL INPUTS

odc **Compressor and fan status when open door:**

no = normal;

Fan = Fan OFF;

CPr = Compressor OFF;

F.C = Compressor and fan OFF.

I1P **Door switch input polarity:**

CL : the digital input is activated by closing the contact;

OP : the digital input is activated by opening the contact.

I2P **Configurable digital input polarity:**

CL : the digital input is activated by closing the contact;

OP : the digital input is activated by opening the contact

I2F **Digital input operating mode:** configure the digital input function:

EAL = generic alarm;

bAL = serious alarm mode;

PAL = Pressure switch;

dFr = Start defrost;

AUS = Not used;

Es = Energy Saving;

onF = remote On/OFF.

did **Time interval/delay for digital input alarm:**(0÷255 min.) Time interval to calculate the number of the pressure switch activation when I2F=PAL. If I2F=EAL or bAL (external alarms), "did" parameter defines the time delay between the detection and the successive signalling of the alarm.

OTHER

Adr **RS485 serial address** (1÷247): Identifies the instrument address when connected to a ModBUS compatible monitoring system.

Rel **Release software:** (read only) Software version of the microprocessor.

Ptb **Parameter table:** (read only) it shows the original code of the dIXEL parameter map.

Prd **Probes display:** (read only) display the temperature values of the evaporator probe Pb2 and the auxiliary probe Pb3.

Pr2 **Access to the protected parameter list** (read only).

6. DIGITAL INPUTS

The Wing series can support up to 2 free contact digital inputs. One is always configured as door switch, the second is programmable in seven different configurations by the **"I2F"** parameter.

6.1 DOOR SWITCH INPUT

It signals the door status and the corresponding relay output status through the **"odc"** parameter:

no = normal (any change);

Fan = Fan OFF;

CPr = Compressor OFF;

F.C = Compressor and fan OFF.

Since the door is opened, after the delay time set through parameter **"dOA"**, the alarm output is enabled and the display shows the message **"dA"**. The alarm stops as soon as the external digital input is disabled again. During this time and then for the delay **"dot"** after closing the door, the high and low temperature alarms are disabled.

6.2 CONFIGURABLE INPUT - GENERIC ALARM (EAL)

As soon as the digital input is activated the unit will wait for **"did"** time delay before signalling the **"EAL"** alarm message. The outputs status don't change. The alarm stops just after the digital input is de-activated.

6.3 CONFIGURABLE INPUT - SERIOUS ALARM MODE (BAL)

When the digital input is activated, the unit will wait for **"did"** delay before signalling the **"BAL"** alarm message. The relay outputs are switched OFF. The alarm will stop as soon as the digital input is de-activated.

